


PARTY BUTTON

SPECIFICATIONS SHEET



Party Button Assembly



Party Button Specifications

The Party Button: Modern interactive art that puts a fun spin on classic traffic interfaces. Press the button and dance to one of twenty randomised party tracks, watching the red and green crosswalk symbols animate and dance with you. Activate your space and encourage great social media opportunities with the Party Button.

SPECIFICATIONS	
Height	2.2 meters
Width	590 mm
Depth	590 mm
Weight	400 kgs
Power	X1 GPIO
Original music tracks	x 20
Original Animations	x 8
Outdoor and Indoor display	✓
Engagement Data	✓
Freestanding, no bolt-down required	✓

Customisation Possibilities

Customise the animations and music for your event. Add more to the existing tracks and animations, or completely new ones to match a theme. Example ideas:

Animations

- Turn the characters into fairies with wings
- Give the characters Santa hats for a christmas theme

Music

- Christmas/holiday themed music
- Include local soundbites, eg. Whalesong, local artists

Usage examples

The Party button is well suited for a variety of display environments, including family events, nightlife and places with milling crowds and queues. Usage can include, but is not limited to:

- Cultural, arts and music festivals
- Shopping centres, theme parks, ski resorts
- Conferences, educational, tech and others

Contact Steph Piper for more information or a quote for your next event.
steph@piper3dp.com